BRINKMANN®

Q-Beam®

FOR Q-BEAM SPOTLIGHTS USING THE 12-VOLT, SEALED BEAM LAMP (BULB)



OWNER'S MANUAL & OPERATING INSTRUCTIONS

IMPORTANT SAFETY WARNINGS

READ AND FOLLOW ALL SAFETY WARNINGS AND INSTRUCTIONS IN THE OWNER'S MANUAL

WARNING

- Never place spotlight lens (face) down when light is on or if it was recently on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause serious property damage. Always turn spotlight off and disconnect from power source when not in use.
- To prevent serious damage to eyesight, never look into spotlight when light is on. Do not shine light into the face of someone else.
- Do not touch lens of spotlight when light is on or if it was recently on. The lens will be hot and could cause serious burns.
- Keep battery clips or cigarette lighter plug dry and out of water at all times.
- Do not place light in water when lamp is hot. Light must be disconnected from power source and cool before placing in water. Sudden extreme changes in temperature could cause bulb or lens to shatter.
- Always disconnect light from power source and allow to cool for at least one minute before removing light from water. Sudden extreme changes in temperature could cause bulb or lens to shatter.
- Do not allow children to handle or operate this spotlight.
- Do not use this product for other than its intended use.
- Do not operate in close proximity of combustible or flammable materials.
- Do not attempt to operate spotlight if cord, plug, bulb or any part of the spotlight is damaged or corroded.
- Do not operate in close proximity of combustible or flammable materials.
- Prior to connecting the light to a battery of an inboard boat, the blower must be activated to remove combustible fumes.
- Connecting the clips while the Q-Beam switch is in the "ON" position may cause arcing or sparking which could ignite fumes.
- 300,000 candlepower products shall be operated from sources equipped with 16 gauge wire or larger, protected by a 20 amp. fuse or breaker.
- 200,000 candlepower products shall be operated from sources equipped with 18 gauge wire or larger, protected by a 15 amp. fuse or breaker.
- Do not use this product for other than its intended use.

USE CAUTION AND COMMON SENSE WHEN OPERATING YOUR SPOTLIGHT.

FAILURE TO ADHERE TO THE SAFETY WARNINGS AND GUIDELINES IN THIS MANUAL COULD RESULT IN BODILY INJURY OR PROPERTY DAMAGE.

SAVE THIS MANUAL FOR FUTURE REFERENCE.

OPERATING INSTRUCTIONS

READ AND FOLLOW ALL SAFETY WARNINGS AND INSTRUCTIONS IN THE OWNER'S MANUAL

Cigarette Lighter Plug

You now own the World's Finest Spotlight. With proper maintenance, your Q-Beam will provide years of superb performance. Depending on the model, Q-Beam operates by connecting directly to a 12-volt battery or by plugging into any U.S. and most foreign 12-volt cigarette lighter receptacles.

Step 1: Place Q-Beam switch in "OFF" position, then insert Q-Beam plug into a 12-volt cigarette lighter receptacle.

Step 2: To activate spotlight, move switch to "ON" position.

Step 3: To deactivate, move switch to "OFF" and unplug from power source.

WARNING: Never place spotlight lens face down when light is on or if it was recently on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause serious property damage. Always turn spotlight off and unplug from power source when not in use.

Battery Clips

AUTOMOBILE BATTERY

Step 1: Place Q-Beam switch in "OFF" position.

Step 2: Connect red clip to positive battery post, then connect black clip to chassis or block.

Step 3: To activate spotlight, move switch to "ON" position.

Step 4: To deactivate, move switch to "OFF". Remove black clip from chassis, then red clip from positive battery post.

BOAT BATTERY

Step 1: Place Q-Beam switch in "OFF" position.

Step 2: Connect red clip to positive battery post, then connect black clip to chassis or block.

WARNING: If boat is an inboard, the blower must be activated to remove combustible fumes prior to connecting light.

Step 3: To deactivate, move switch to "OFF". Remove red clip from positive battery post, then black clip from negative battery post.

WARNING: Connecting the clips while Q-Beam switch is in "ON" position may cause arcing or sparking which could ignite fumes.

Use only Brinkmann's 12-volt, sealed beam lamp which is designed for Q-Beam spotlights as a replacement. Use of any other lamp may result in poor performance and may damage your Q-Beam.

Step 1: Place Q-Beam switch in "OFF" position, then disconnect spotlight from power source (cigarette lighter receptacle or battery terminals). Allow lamp to cool completely before proceeding.

Step 2: Remove the two screws from top and bottom of front housing. See Figure 1.

Step 3: Lay spotlight face (lens) up on a flat surface.

Step 4: Holding rear housing securely, slowly lift off front housing.

NOTE: Do not lift up or pull if the lamp remains in front housing. Firmly grasp front housing with both hands and gently push down lamp onto rear housing with thumbs.

Step 5: With front housing removed, gently lift the lamp (bulb) up, being careful not to damage the wire connections inside.

Step 6: Disconnect lamp wires by grasping connectors and gently pulling straight out. See Figure 2.

Step 7: To install new lamp, reconnect lamp wires at the connectors.

Step 8: Set lamp onto rear housing. Replace front housing.

Step 9: Align screw holes and secure with the two screws that were removed in Figure 1. Do not over-tighten.



Figure 1



Figure 2

Q-BEAM ACCESSORIES

Rechargeable Battery Pack With Carrying Case

12-volt rechargeable battery pack adds total mobility to your Q-Beam. Includes cigarette lighter receptacle, 120-volt charging transformer and a heavy-duty, woven nylon carrying case with shoulder strap.

Model 802-1724-1 Black

Model 802-1725-1 Green Camo



Snap-On Lens Filter

Filter lens easily snaps-on to Q-Beam spotlight for color and visual effect.

Model 802-1703-1	**Amber**
Model 802-1703-2	**Red**
Model 802-1703-3	**Blue**
Model 802-1703-4	**Assortment Pack (1 Amber, 1 Red, 1 Blue)**

Lighter Plug Extension Cord

Features a 15-ft. cord with a cigarette lighter plug and receptacle.

Model 802-1706-0

LOOK FOR THESE ACCESSORIES AT YOUR LOCAL RETAILER WHERE Q-BEAMS ARE SOLD, OR ORDER DIRECT BY CALLING 1-800-468-5252

Q-BEAM ACCESSORIES

Carrying Case

Black, vinyl carrying case is ideal for storage and transport of your Q-Beam hand-held spotlight.

Model 802-1702-0

Wall Mount Bracket

Mounts to any flat surface for storage of Q-Beam spotlights. Screws included.

Model 802-1708-0

Pigtail Adapters

Pigtail adapter with battery terminal clips allow Q-Beam spotlights with cigarette lighter plug to operate directly from a 12-volt battery.

(2 Ft. Cord) Model 802-1704-0

(10 Ft. Cord) Model 802-1705-0





REPLACEMENT BULB (BLACK MAX)

Glare-free 400,000 CP, 12-volt bulb is an original replacement for Q-Beam Black Max.

Model 802-1718-0

REPLACEMENT BULB (BIG MAX)

400,000 CP, 12-volt bulb is an original replacement for Q-Beam Big Max.

Model 802-1717-0

REPLACEMENT BULB (BLUE MAX)

Glare-free 300,000 CP, 12-volt bulb is an original replacement for Q-Beam Blue Max.

Model 802-1714-0

REPLACEMENT BULB (SPOT/FLOOD)

200,000/100,000 CP, 12-volt bulb is an original replacement for Q-Beam Spot/Flood.

Model 802-1700-0

REPLACEMENT BULB (SUPER SPOT 300,000)

300,000 CP, 12-volt bulb is an original replacement for Q-Beam Super Spot.

Model 802-1719-0

REPLACEMENT BULB (SUPER SPOT 200,000)

200,000 CP, 12-volt bulb is an original replacement for Q-Beam Super Spot.

Model 802-1701-0

LOOK FOR THESE ACCESSORIES AT YOUR LOCAL RETAILER WHERE Q-BEAMS ARE SOLD, OR ORDER DIRECT BY CALLING 1-800-468-5252

©2004 The Brinkmann Corporation
Dallas, Texas 75244 U.S.A
www.brinkmanncorp.com

1-YEAR LIMITED WARRANTY

For 1-year from date of purchase, The Brinkmann Corporation warrants the Q-Beam Sealed Beam Spotlight against defects due to workmanship or materials to the original purchaser. The Brinkmann Corporation's obligations under this warranty are limited to the following guidelines:

- This warranty does not extend to the bulb.
- This warranty does not cover spotlights that have been altered or damaged due to: normal wear, abuse, improper maintenance, improper use, disassembly of parts and/or attempted repair by anyone other than an authorized employee of The Brinkmann Corporation.
- This warranty does not cover surface scratches or weathering as this is considered normal wear.
- Warranty service is limited to repair or replacement of spotlights which prove defective under normal use and which upon examination shall indicate to Brinkmann's satisfaction, they are defective. If Brinkmann confirms the defect and approves the claim, Brinkmann will elect to repair or replace the spotlight as covered by the terms of this warranty.
- This warranty extends to the original purchaser only and is not transferable or assignable to subsequent purchasers.

The Brinkmann Corporation requires reasonable proof of purchase. Therefore, we strongly recommend that you retain your sales receipt or invoice. To obtain repair or replacement of your Q-Beam Sealed Beam Spotlight under the terms of this warranty, please call Customer Service Department at 1-800-527-0717 for a Return Authorization Number and further instructions. A receipt will be required. Spotlights returned to Brinkmann must include your name, address and telephone number. Please make sure the light is properly packed, postage prepaid, and insured. **A Return Authorization Number must be clearly marked on the outside of the box.** The Brinkmann Corporation will not be responsible for any spotlights forwarded to us without a Return Authorization Number.

EXCEPT AS ABOVE STATED, THE BRINKMANN CORPORATION MAKES NO OTHER EXPRESS WARRANTY.

THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO 1-YEAR FROM THE DATE OF PURCHASE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

ANY LIABILITY FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM THE FAILURE OF THE Q-BEAM SEALED BEAM SPOTLIGHT TO COMPLY WITH THIS WARRANTY OR ANY IMPLIED WARRANTY IS EXCLUDED. CUSTOMER ACKNOWLEDGES THAT THE PURCHASE PRICE CHARGED IS BASED UPON THE LIMITATIONS CONTAINED IN THE WARRANTY SET OUT ABOVE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

140-0003-0
10/96